



*Nordic Shimmer*

# Nordic Milk

Complexity: **Easy** | Topcoating: **Craft Oil 2K Frost**  
 Brushing: **Optional** | Finish: **Natural matte**

White pigmented oil is massaged into your wood floor to smooth out details and bring extra luster.

*Nordic Milk applied on brushed white oak.  
 Results will vary depending on the colour and type of your original wood floor.*

Products used
 <p><b>Bona Nordic Tone</b></p>
 <p><b>Bona Craft Oil 2K Frost</b></p>

Directions	Drying time
1. Prepare the floor and end the sanding with grit 120. Vacuum carefully.	
2. Apply Bona Nordic Tone using an application sleeve (8-10 m <sup>2</sup> /litre).	5-10 h
3. Thoroughly stir the oil and apply it to the floor using a squeegee or red buffing pad (approx. 20 m <sup>2</sup> /lit).	
4. Allow the oil 15-30 minutes to be absorbed. Buff the surface with a buffing machine equipped with a red pad, adding more oil as required.	15-30 min
5. After another 15-30 minutes, remove surplus oil using cotton cloths.	15-30 min
6. For a flawless finish, buff a final time using a Bona Woolpad.	12-24 h

#### Other information

- To protect the pigmentation consider applying a coat of Bona Hardwax as a final treatment. The extra matt version is preferable to maintain the look.

#### Special considerations

For greater wear resistance and to protect the pigmentation it is recommended to end the treatment with an application of Bona Hardwax Oil.

*This guide describes the overall treatment process of wooden floors and does not replace technical and safety datasheets, that are subject to change, and must be observed prior to use. The drying times suggested are typical drying times at 20°C/60% RH, and must be adjusted to local indoor climate conditions.*