

Malibu Dreams

# Malibu Natural

Complexity: **Moderate** | Topcoating: **Traffic Neutral**  
 Brushing: **Optional** | Finish: **Natural matte**

Natural oil and Bona Traffic Natural for a smooth as silk feeling. Amazing to walk and invisible to the eye.

*Malibu Natural applied on brushed white oak.  
 Results will vary depending on the colour and type of your original wood floor.*

Products used
 <p><b>1x Bona Craft Oil 2K Neutral</b></p>
 <p><b>2x Bona Traffic Natural</b></p>

Directions	Drying time
1. Prepare the floor and end the sanding with grit 120. Vacuum carefully.	
2. Mix the oil with hardener and apply it to the floor using a stainless-steel trowel, squeegee or red buffing pad (approx. 30 m <sup>2</sup> /lit).	15-30 min
3. After 15-30 minutes, buff the surface with a buffing machine equipped with a red pad. Add more oil as required.	15-30 min
4. After another 15-30 minutes, remove surplus oil using cotton cloths. Let surface dry.	8-12 h
5. Apply Bona Traffic Natural using a Bona Microfiber Roller 11 mm and let dry (approx. 8-10 m <sup>2</sup> /lit).	2-3 h
6. Make a light intermediate abrasion to reduce any grain raise using Bona Diamond Abrasives grit 120. Vacuum or dust wipe.	
7. Apply a second coat of Bona Traffic Natural.	12-24 h
8. An additional coat of lacquer may be needed in high a areas.	

#### Other information

- Bona Traffic Natural has a rougher surface than traditional lacquers. For highly trafficked commercial areas, consider replacing with Bona Traffic HD Extra Matt for a similar appearance with easier clean up.

*This guide describes the overall treatment process of wooden floors and does not replace technical and safety datasheets, that are subject to change, and must be observed prior to use. The drying times suggested are typical drying times at 20°C/60% RH, and must be adjusted to local indoor climate conditions.*