

Nordic Shimmer

Nordic Ash

Complexity: **Easy** | Topcoating: **Craft Oil 2K Ash**
 Brushing: **Optional** | Finish: **Natural matte**

Raw wood meets ash grey and comes out a winner.
 For a rustic Nordic look.

*Nordic Ash applied on brushed white oak.
 Results will vary depending on the colour and type of your original wood floor.*

Products used



Bona Craft Oil 2K Ash

Directions

Drying time

1. Prepare the floor and end the sanding with grit 120. Vacuum carefully.	
2. Waterpop the surface by applying a thin coat of water. A sponge or short-haired roller can be used for this. Restrain the amount of water yet make sure to wet all the wood.	12 h
3. Mix the oil with hardener and apply it to the floor using a stainless-steel trowel, squeegee or red buffing pad (approx. 30 m ² /lit).	
4. After 15-30 minutes, buff the surface with a buffing machine equipped with a red pad.	15-30 min
5. Make another pass with more oil.	
6. After another 15-30 minutes, remove surplus oil using cotton cloths.	15-30 min
7. For a flawless finish, buff a final time using a Bona Woolpad.	8-12 h

Other information

- It is recommended to always waterpop prior to oil application to ensure colour intensity and uniformity.
- In high traffic areas, consider ending with two layers of Bona Traffic HD. Extra Matt is recommended to preserve the look.

Special considerations

Consider complementing the treatment with Bona Traffic/HD for lower maintenance frequency and to protect the pigmentation.

This guide describes the overall treatment process of wooden floors and does not replace technical and safety datasheets, that are subject to change, and must be observed prior to use. The drying times suggested are typical drying times at 20°C/60% RH, and must be adjusted to local indoor climate conditions.