

Create your own wood story

Application of accent colours - one coat each of two different oils

1. Sand according to sanding sequence for Brushed.
2. Waterpop for more intense colouration if desired. If waterpopping, allow to dry until the following day.
3. Apply a thin coat of the mixed Bona Craft Oil 2K to the floor using a <175 rpm buffer and a red buffing pad working back and forth with the grain of the wood when possible. For areas the buffer cannot reach, use a trowel or brush to apply the oil.
4. Allow the oil to penetrate the wood surface for 15-30 minutes.
5. Remove excess oil using a buffer and a clean Bona Cotton Cloth wrapped around a buffing pad. Change cloth as needed.
6. Allow oil to dry thoroughly before applying the next coat.
7. Mix the second oil and apply it in the same manner as the first coat.
8. Remove excess oil using a buffer and a clean Bona Cotton Cloth wrapped around a buffing pad. Change cloth as needed.
9. Allow oil to dry thoroughly before applying the next coat (>12 hours).

Protection with Bona Traffic HD/Traffic/Traffic Natural is optional but highly recommended for increased durability.

10. Vacuum and clean the floor with a Bona Cleaning or Dusting Pad.
11. Apply two coats of the preferred Traffic lacquer with sufficient drying time between coats. Intermediate abrasion between coats is normally not necessary.



Sanding sequence
for Brushed

