

Bona Naturale Repair Kit

Technical data sheet

Naturale is a favourable surface treatment that allows for local spot repairs. Bona Naturale Repair Kit contains all the necessary articles to make a spotless superficial repair regardless if the surface is originally treated with Naturale 1-comp, Naturale 2-comp, Naturale Base or UV-Naturale.

- Economic solution for scratched and damaged floors.
- Blends in with rest of floor.
- Easy to follow instructions with pictures on the box.

Technical data

Kit Includes:	1 dl Bona Naturale Top 1 dl Bona Naturale Base 1 tape roll 2 sanding papers grit 100 2 brushes
Drying time:	Bona Naturale Base: 1-2 hours* Bona Naturale Top: 2-3 hours*
Safety:	Unclassified
Shelf life:	2 years from the date of production in unopened original container.
Storage/Transport:	The temperature must not fall below +5°C or exceed +25°C during storage and transport.
Disposal:	Wastes and emptied containers should be handled in accordance with local regulations.
Pack size:	12 kits per box

**under normal climate conditions, 20°C/60% R.H. It takes approximately one week for the surface treatment to reach full hardness. Avoid heavy load during this time.*

Directions for use

WARNING: Bona Naturale Top and Base leaves a permanent film on the surface. Results may vary depending on individual application techniques, severity of damage and previous sun exposure on floor. If in doubt, make a test in an inconspicuous corner of the room prior to use.

Damages down to bare wood

1. Vacuum and then clean the damaged area using Bona Cleaner.
2. Sand the affected area with the included sand paper to remove dirt and sharp edges.
3. Vacuum and/or wipe clean.
4. Eventual indentations can be filled with a wood filler prior to next step. Abrade lightly after using filler.
5. Apply one layer of Bona Naturale Base and allow to dry.
6. Abrade lightly to remove grain raise.
7. Tape around the damaged board(s) or wood block(s).
8. Apply one layer of Bona Naturale Top to the whole wood board(s) or wood block(s).
9. Remove the tape immediately.
10. Allow to dry.

Superficial damages

1. Vacuum and then clean the damaged area using Bona Cleaner.
2. Sand the affected area with the included sand paper to remove dirt and sharp edges.
3. Vacuum and/or wipe clean.
4. Tape around the damaged board(s) or wood block(s).
5. Apply one layer of Bona Naturale Top to the whole wood board(s) or wood block(s).

Floor Care



Bona Naturale Repair Kit

Technical data sheet

6. Remove the tape immediately.
7. Allow to dry.

Floor Care

