



# Bona QUANTUM<sup>®</sup> R851

Silane-based Wood Floor Adhesive

One-Component, silane-based wood floor adhesive



Bona QUANTUM<sup>®</sup> - R851 is a silane-based wood flooring adhesive that provides exceptional “green grab strength. Its elastomeric characteristics allow the adhesive to move with the wood as it expands and contracts over the life of the floor.

- Easy to apply – no arm fatigue
- Unsurpassed ridge stability provides maximum adhesive transfer
- Excellent “Green Grab” means the floor stays place
- Easy to clean – will not harm or etch the finish on pre-finished floors; will not stain hands
- Zero VOC's
- GREENGUARD Gold Certified



# Bona QUANTUM<sup>®</sup> R851

Silane-based Wood Floor Adhesive

## One-Component, silane-based wood floor adhesive

### PHYSICAL CHARACTERISTICS

**Ingredients** – Calcium carbonate, silane modified prepolymer, plasticizers, amorphous silica

**Base** – Silane Modified-Prepolymer

**Color** – Cream

**Viscosity** – 100 +/-10 Pa\*s at a shear rate of 5<sup>^</sup>-1 sec

**Density** – 13.93 lbs./gallon

**VOC Content** – ZERO VOC

**Max Shear Strength** – 340psi (at final cure; lap shear test, 1mm gap) ISO 17178

**Max Elongation** – 200% (ISO 17178)

**Water Vapor Permeability** - < 0.7 g/m<sup>2</sup>-24 hour-mmHG @ 2000g/m<sup>2</sup>

**Sound Reduction Rating** – Meets ASTM E492-09 and ASTM E90-04 STC and IIC with ceiling; STC 63, IIC 69.

**Moisture Levels** – Moisture protection up to 18lbs or 95% RH, 6% Tramex. For maximum moisture protection ensure 100% coverage of adhesive to substrate.

**Odor** – Non-offending

**Flash Point** – >100° C (212°F) (Pensky-Martens)

**Stability** – 12 months from date of manufacture in unopened, original packaging

**Packaging** – 3-gallon containers

### APPLICATION CHARACTERISTICS

**Spread Rating** – Easy to spread, maintains excellent ridge stability

**Open Time**- Up to 60 minutes @70°F and 50% RH\*

**Coverage** – See “Trowel Notch Requirements” for spread rate

**Curing** – Light foot traffic - 8-10 hours

Furniture, fixtures - 12-24 hours

Unfinished floor sanding - after 24 hours

\*Dependent of temperature and humidity. Higher humidity decreases open time while lower humidity increases open time.

### RECOMMENDED USE

Commercial and residential. Use with solid or engineered prefinished and unfinished flooring; on, above or below grade<sup>1</sup>. May be used on both wood and concrete substrates<sup>2</sup>.

<sup>1</sup>Read and follow flooring manufacturer instructions, recommendations, and limitations as to the suitability of a particular flooring product to certain jobsite conditions and installation methods.

<sup>2</sup>After proper site conditions, moisture testing results and substrate preparation have been met.

See “Directions for Use” for acceptable jobsite conditions.

### RESPONSE

**BEFORE USING, READ ALL DIRECTIONS AND MATERIAL SAFETY DATA SHEETS. KEEP OUT OF REACH OF CHILDREN.** FOR TECHNICAL ADVICE: Call Bona US at 800-872-5515. In case of eye contact, flush immediately with water. Get medical attention if irritation occurs. For skin, wash thoroughly with soap and water. If affected by inhalation, remove to fresh air. If swallowed, do not induce vomiting. Get medical attention.

### ACCLIMATION AND SITE CONDITIONS

Building climate control system must be functioning with a temperature of 65°F–80°F and maximum relative humidity of 65% for 72 hours before flooring is installed, during installation, and for 72 hours after installation. Ideal conditions are 65-70°F and 45-55% RH. Acclimate Bona QUANTUM R851 adhesive to room temperature of the installation, usually overnight.



# Bona QUANTUM<sup>®</sup> R851

Silane-based Wood Floor Adhesive

**One-Component, silane-based wood floor adhesive**

## MOISTURE TESTING

For concrete slabs, using standard application, conduct moisture testing per ASTM test methods F 1869 Test for Measuring Moisture Vapor Emission Rate (MVER) of Concrete Subfloor Using Anhydrous Calcium Chloride, and/or F 2170 Test Method for Determining Relative Humidity in Concrete Floor Slabs Using In Situ Probes. Contact ASTM International to obtain copies of the test methods before proceeding. **MVER using ASTM F 1869 (Calcium chloride test) shall not exceed 12 lbs/24 hours/1000 square feet. Relative Humidity using ASTM F 2170 (RH Probe test) shall not exceed 85%. If MVER readings exceed 12 lbs. or 85% but are less than 18 lbs. or 95%, use Bona<sup>®</sup> RollGuard or Bona<sup>®</sup> R540 Moisture Barrier/Primer (See label for detailed instructions) or use a Moisture Barrier Plus (MBP) trowel, or a ¼" x ¼" v-notch and spread the adhesive at a coverage rate of up to 35 square feet per gallon. For maximum moisture protection ensure 100% transfer and coverage of adhesive to concrete subfloor creating an uninterrupted and continuous membrane of adhesive. When using a Tramex measuring device to identify moisture levels in cementitious based substrates, use the Tramex measuring device to find the highest reading in the area to be installed then run highest reading in the area to be installed. As a general guideline for floors with no in-floor heating system, if the Tramex reading is below 4%, the Bona Moisture Barrier Trowel (MBP) clip-on trowel, a ¼" x ¼" V-notch trowel, Bona RollGuard or Bona R540 Moisture Barrier/Primer will not be necessary. If the reading is between 4% and 6%, either use the MBP Trowel, a ¼" x ¼" V-notch trowel at a coverage rate of up to 35 square feet per gallon. Alternatively, Apply Bona RollGuard or Bona R540 Moisture Barrier/Primer prior to adhesive application. For wood substrates, follow flooring manufacturer's guidelines including moisture content and required moisture measuring methods.**

## SUBSTRATE PREPARATION

Substrate must be clean, smooth, dry, free of loose material and structurally sound, with the surface slightly textured (similar to a light broom finished concrete) for best adhesion. Remove adhesive residue, paint, concrete curing compounds or other contaminants that may affect adhesive bond. Sandblasting shot blasting or scarifying may be necessary to completely remove some of these residues. Surface cracks, grooves, depressions, control joints or other non-moving joints, and other irregularities must be filled or smoothed with a Portland Cement based patching and leveling compound. Substrate must be level to 3/16" in a 10-foot span. To achieve moisture protection when a patch or leveling compound is used, first apply one coat of Bona RollGuard at 200-250 SF/5L or two coats of Bona R540 at 400 SF / 5L. Dry sand should be broadcast into the final coat of moisture barrier (while wet, until rejection) prior to the application of leveling compounds. Apply leveling compound following manufacturer's instruction. Do not install wood flooring before the compound has fully cured. Do not install over expansion joints or other moving joints in a concrete slab. Slab temperature must be between 55°F and 95°F. Suitable substrates include concrete, plywood, Warmboard<sup>®</sup>, cork, particle or OSB, stone, ceramic, terrazzo, radiant heat flooring (refer to manufacturer's recommended installation instructions), and dry above-grade gypsum underlayment, recycled-rubber underlayment.

## PRODUCT LIMITATIONS

Bona QUANTUM<sup>®</sup> R851 will not prevent moisture-related damages to wood flooring originating from the top, sides or ends of flooring (water leaks, puddles, hydrostatic head, etc.) nor does it eliminate other moisture or installation related issues such as improper acclimation of flooring or the effects of jobsite temperature and humidity.



# Bona QUANTUM<sup>®</sup> R851

Silane-based Wood Floor Adhesive

## One-Component, silane-based wood floor adhesive

### DO NOT USE BONA QUANTUM<sup>®</sup> R851

- On wet, contaminated or friable surfaces
- Over concrete curing compounds, sealers or other surface treatments that could affect adhesion
- On areas subject to hydrostatic head
- On cutback residue, or over vinyl/VCT
- On chemically treated woods (stain, preservatives, etc.)
- As a leveling compound
- As a moisture barrier over leveling compounds or patches.

### SPREADING ADHESIVE AND LAYING FLOORING

Pour adhesive along the length of the desired install location. Spread adhesive on the substrate while holding the Bona trowel at a 90° angle, using a smooth semicircular motion. Do not leave any puddles of adhesive. Set the flooring into the adhesive while the adhesive is still wet. At the start of the installation, and repeatedly throughout the installation, pull a freshly laid board to ensure 100% coverage on substrate. Do not allow more than 45 minutes of open time before setting flooring into the adhesive. (at 70°F and 50% RH; higher humidity can decrease open time, lower humidity can increase open time). **DO NOT SET FLOORING INTO ADHESIVE THAT HAS SKINNED OVER, REMOVE ADHESIVE AND REAPPLY.**

### BACK TROWEL METHOD

Utilizing the flat side of the Bona<sup>®</sup> 1500g trowel or the Bona<sup>®</sup> 1250g trowel, skim coat Bona QUANTUM<sup>®</sup> R851 onto subfloor creating a smooth surface free of voids. While the skim coat of adhesive is still wet, apply Bona QUANTUM R851 with either trowel.

### CLEAN-UP

Clean adhesive from the surface of the floor while wet. Use mineral spirits on a clean white cloth.

### STORAGE

Store in a climate controlled environment. Do not store for extended periods in excess of 90°F (32°C). Freeze thaw stable.

















# Bona QUANTUM® R851

Silane-based Wood Floor Adhesive

One-Component, silane-based wood floor adhesive

Trowel Selection • Sélection de la truelle

Description La Description		Use Utilisation	Coverage Rate Taux de couverture	Moisture Protection Protection contre l'humidité
 7/16" V-notch with MBP spacer	Bona Moisture Barrier Plus (MBP) Trowel	Solids up to 9" wide and 3/4" thick Engineered up to 16" wide and 3/4" thick	up to 35 sq. ft./gallon**	≤ 18 lbs. / 95% RH
 1/4"x1/4" V-notch	1/4" x 1/4" Bona V-notch Trowel			
 Truelle dentée en V de 11 mm avec entretoise MBP	Truelle Bona Moisture Barrier Plus (MBP)	Planche en bois massif jusqu'à 23 cm (9 po) de largeur et 2 cm (3/4 po) d'épaisseur Plancher d'ingénierie jusqu'à 40 cm (16 po) de largeur et 2 cm (3/4 po) d'épaisseur	jusqu'à 3,25 m <sup>2</sup> / 4 litres**	≤ 8,16 kg (18 lb)/95 % HR
 Truelle dentée en V de 6,35 mm x 6,35 mm	Bona Truelle dentée en V de 6,35 mm x 6,35 mm			
 5/16"x5/16"x7/16" V-notch	Bona 1500G Trowel	Solids up to 9" wide and 3/4" thick Engineered up to 16" wide and 3/4" thick	up to 50 sq. ft./gallon**	≤ 12 lbs. / 85% RH trowel only ≤ 15 lbs. / 87% RH over Bona with back-trowel‡ ≤ 18 lbs. / 95% RH over Bona RollGuard or Bona R540*
 Truelle dentée en V de 8 mm x 8 mm x 11 mm	Truelle Bona 1500G			
 1/4"x1/4"x7/16" V-notch	Bona 1250G Trowel	Solids up to 5" wide and 3/4" thick Engineered up to 8" wide and 3/4" thick	up to 60 sq. ft./gallon**	≤ 12 lbs. / 85% RH trowel only ≤ 15 lbs. / 87% RH over Bona with back-trowel‡ ≤ 18 lbs. / 95% RH over Bona RollGuard or Bona R540*
 Truelle dentée en V de 6,35 mm x 6,35 mm x 11 mm	Truelle Bona 1250G			
 7/32"x13/64"x25/64" V-notch	Bona Engineered Flooring Trowel (EF)	Engineered flooring only up to 7" wide and 3/4" thick	up to 75 sq. ft./gallon	≤ 6 lbs. / 80% RH trowel only**
 Truelle dentée en V de 5,5 mm x 5,15 mm x 9,92 mm	Plancher d'ingénierie Truelle Bona (EF)			
 5/32"x5/32"x5/32" V-notch	Bona 1000F Trowel	Parquet (12"x12") over smooth substrates Acoustical Underlayment Pad	up to 85 sq. ft./gallon**	≤ 6 lbs. / 80% RH trowel only**
 Truelle dentée en V de 6,25 mm x 6,25 mm x 6,25 mm	Truelle Bona 1000F			
 7/16"x7/16"x3/4" V-notch	Bona Engineered Flooring Plus Trowel (EFP)	Engineered flooring only up to 7 1/2" wide and 5/8" thick	up to 70 sq. ft./gallon	≤ 3 lbs. / 75% RH trowel only**
 Truelle dentée en V de 11 mm x 11 mm x 1,9 mm	Plancher d'ingénierie plus Truelle Bona (EFP)			

‡Back Trowel Method: Utilizing the flat side of the Bona® 1500G or the Bona® 1250G trowel, skim coat Bona Quantum® R851 onto subfloor creating a smooth surface free of voids. While the skim coat of adhesives is still wet, apply Bona Quantum R851 with either trowel. \*Refer to Individual Product Technical Data Sheets for detailed information.

\*\*Coverage rates are dependent of board width and subfloor flatness (must be flat within 3/16" over 10 foot radius), substrate porosity (recommended CSP 3), pressure and angle of trowel during application.

\*\*\*Two coats of a dedicated moisture barrier will provide additional protection; see individual product Technical Data Sheets for detailed information.

‡Application d'une fine couche sur le support avec la partie plate de la truelle : En utilisant le côté plat de la truelle Bona® 1500g ou de la truelle Bona® 1250g, appliquez une fine couche de Bona Quantum® R851 sur le sous-plancher pour obtenir une surface lisse sans vides. Pendant que la couche de l'adhésif est encore humide, appliquez le Bona Quantum R851 avec l'une ou l'autre des truelles.

\*Pour plus d'informations, consultez les fiches techniques des différents produits.

\*\*Les taux de couverture dépendent de la largeur du panneau et de la planéité du sous-plancher (doit être plat à 3/16" près sur un rayon de 10 pieds), de la porosité du substrat (CSP 3 recommandé), de la pression et de l'angle de la truelle lors de l'application.

\*\*\*Deux couches d'une barrière anti-humidité spécifique fourniront une protection supplémentaire ; voir les fiches techniques des produits individuels pour des informations détaillées.



# Bona QUANTUM<sup>®</sup> R851

Silane-based Wood Floor Adhesive

**One-Component, silane-based wood floor adhesive**

## ORDER INFORMATION

Item #	Description	Size	No. Case	Lbs./Case
BR85106100USBO	Bona QUANTUM <sup>®</sup> - R851	3 gal	1	44.4 lbs.