



Bona Prep®

Conditions and prepares existing wood floor finish to optimize adhesion for a recoat.



Conditions and prepares existing wood floor finish to optimize adhesion of a new coat of finish.

Bona Prep® is a specially formulated recoat adhesion system for all types of polyurethane finished hardwood floors, including factory prefinished floors. Bona Prep conditions and prepares the existing finish to optimize adhesion of the new coat of finish.

- Removes scuffs and surface scratches, rather than just covering them
- Convenient – pre-mixed and ready to use
- Easy – doesn't require special training or certification
- Fast – just spray and buff



Bona Prep®

Conditions and prepares existing wood floor finish to optimize adhesion for a recoat.

TECHNICAL DATA

Ingredient	CAS Number	Role
Water/Aqua	7732-18-5	Solvent
PPG-2 Methyl Ether	34590-94-8	Solvent
Methoxyisopropanol	107-98-2	Solvent
Dodecyl Benzene Sulfonate	25155-30-0	Surfactant
Sodium Laureth Sulfate	7757-82-6	Surfactant
Hexylene Glycol	107-41-5	Solvent
Lauramide DEA	120-40-1	Surfactant
Sodium Xylene Sulfonate	1300-72-7	Surfactant
EDTA, Tetrasodium	13235-36-4	Chelating Agent
Sodium Polyacrylate	2594415	Dispersing Agent
Ethanol	64-17-5	Solvent
Polymeric Orange Colorant	Proprietary	Colorant
Polymeric Blue Colorant	Proprietary	Colorant
Benzisothiazolinone	2634-33-5	Preservative
Methylisothiazolinone	2682-20-4	Preservative
pH-value:	7.0-8.0	
Solids content:	<1%	
Density:	8.33 lbs./gallon (1.0 S.G.)	
US Regulatory VOC:	<2%	
Dilution:	Do not dilute	
Odor:	Light antiseptic	
Color:	Amber	
Packaging:	32 oz. spray, 1-gallon jug, and 5-gallon pail	
Shelf life:	1-year shelf life	
Storage/Transport:	Bona Prep® should be stored in a climate-controlled environment. Keep from freezing. Do not store above 100° F (38° C).	
Application Tools:	Bona® PowerScrubber or a buffer with a conditioning pad	
Drying time:	15-20 minutes	
Clean-up:	Clean all tools and equipment with warm water.	
Disposal:	Dispose of any remaining product in accordance with local, state, and federal regulations.	
Certificates:	GreenGuard Certified	

BEFORE USING, READ ALL DIRECTIONS AND MATERIAL SAFETY DATA SHEET. FOR TECHNICAL ADVICE: Call Bona US at 800-872-5515



Bona Prep®

Conditions and prepares existing wood floor finish to optimize adhesion for a recoat.

RECOMMENDED USE

Prep is intended for all polyurethane-finished hardwood floors, including aluminum oxide, ceramic, and other factory

prefinished floors, that have not been maintained with acrylic maintenance products.

COMPATIBILITY

Do not use this product on any floor that has been waxed, polished, oiled or has been maintained with a commercial maintenance coating. **ALWAYS PREPARE A SAMPLE OR TEST AREA TO DETERMINE COMPATIBILITY,**

APPEARANCE AND DESIRED RESULTS. For factory prefinished flooring, contact the manufacturer for specific recoat recommendations.

MIXING INSTRUCTIONS

This product is designed to be used full-strength as packaged.



Bona Prep®

Conditions and prepares existing wood floor finish to optimize adhesion for a recoat.

DIRECTIONS

PREP SYSTEM WITH BONA POWERSCRUBBER®: 1. Vacuum or sweep the floor thoroughly to remove loose dirt and grit. Fit the Bona PowerScrubber with white cleaning brushes and fill it with Bona Prep. DO NOT DILUTE BONA PREP. 2. Using the Bona PowerScrubber, clean with the grain of the wood when possible, moving the Bona PowerScrubber up and back in the same path. Only dispense Bona Prep on the forward pass. Depending on how dirty the floor is, it may be necessary to dispense Bona Prep on the backward pass or make a second pass. On subsequent passes, overlap the previous pass by 20%. Continue the process until the entire floor is clean. 3. When dry, abrade the entire floor using the Bona Multidisc with Bona Diamond 240-grit disc for best results. Alternatively, abrasion can be done using a Bona conditioning pad driving two or three 240-grit Bona Diamond Abrasives. All these options will ensure abrasion of the edges next to any over wood and, in the grain pattern, optimizing the adhesion of the finish topcoat. Beveled edges and visibly unabraded areas should be cleaned and abraded by hand. 4. Thoroughly clean the floor by vacuuming, then using a Bona PowerScrubber (white brushes and water) to remove the fine Diamond abrasion dust; or wet tacking with water, Bona® Microfiber Mop and Bona® Microfiber Wet Cleaning Pad. 5. Allow the floor to dry completely. Then, within 2 hours, apply a Bona waterborne or oil-modified finishing system. NOTE: If recoating a factory prefinished floor, use

only the Bona Traffic HD® family of finishes.

PREP SYSTEM WITHOUT A BONA POWERSCRUBBER:

1. Vacuum or sweep the floor thoroughly to remove loose dirt and grit. 2. Use Bona Prep as a spray buff solution with a standard speed (175 rpm) buffer and a Bona® Conditioning Pad. Spray Bona Prep over a large section of the floor (approximately 3'x12') at 2,000 square feet per gallon. 3. Remove all residues immediately before spray buffing the next section, using a Bona® Microfiber Mop dampened with Bona Prep. NOTE: Overlap sections to ensure that no areas are missed. 4. When dry, abrade the entire floor using the Bona Multidisc with Bona Diamond 240-grit disc for best results. Alternatively, abrasion can be done using either a Bona conditioning pad driving two or three 240-grit Bona Diamond Abrasive or a second Bona conditioning pad. All these options will ensure abrasion of the edges next to any over wood and in the grain pattern and optimize the adhesion of the finish topcoat. Beveled edges and visibly unabraded areas should be cleaned and abraded by hand. 5. Thoroughly vacuum the floor, then wet tack with water, Bona® Microfiber Mop, and Bona® Microfiber Wet Cleaning Pad. 6. Allow the floor to dry completely. Then, within 2 hours, apply a Bona waterborne or oil-modified finishing system. NOTE: If recoating a factory prefinished floor, use only the Bona Traffic HD® family of finishes.

Bona US
24 Inverness Place East, Suite 100
Englewood, Co. 80128