



Item	Ref	Description
1	ASO316011	Handle cover
2	ASO316005	Protection rubber,strip/handle
3	ASO316504	Start brake axle/handle, compl.
4	ASO311006	Blocking axle to handle
5	ASO942305	Spring SF-VFR 1,25x9x3,75 left
6	ASO316012	Handle level
7	ASO957942	Screw Ejot PT K40x20 WN1452
8	ASO957913	Screw Torx MRT-TT M5x10 fzb
9	ASO957953	Screw Ejot Delta PT50x30 WN5452
10	ASO942112	Spring SF-VFR 1,5 x 7 x 6 right
11	ASO957932	Screw Ejot PT K30x20 WN1452
12	ASO903869	Micro switch D3V-16-IC5
13	ASO319922	Velcro incl. screws
14	ASO319923	Dusttube clips incl. screws
15	ASO319944	Cable for handle