


Bona Standard 8 Belt Sander AM0001504 Standard 8 complete



Bona Standard 8 Belt Sander AM0001504 Standard 8 complete

.	AS2101.01	Machine chassis
.	AS2101.02	Pin screw
.	AS2101.03	Lock nut
.	AS2101.04	Clamping lever
.	AS2101.05	Washer
.	AS2101.06	BUMPER REG 8in
.	AS2102.01	PRESSURE REGULATING SCREW
.	AS2102.02	SPRING PRESSURE PLATE
.	AS2102.03	Pressure spring
.	AS2103.01	SQUARE HEAD BOLT (REG 8)
.	AS2103.02	Lock nut
.	AS2104.01	DRUM COVER
.	AS2104.02	Cover lock
.	AS2104.03	Mounting screw
.	AS2104.04	Hinges
.	AS2105.01	DRUM COVER HEAD
.	AS2105.02	MOUNTING SCREW
.	AS2105.03	Spring washer
.	AS2105.04	SPACER
.	AS2105.05	Screw
.	AS2105.06	Washer
.	AS2105.07	Lock notch
.	AS2105.08	Mounting screw
.	AS2105.09	Hinge bolts

.	AS2106.01	Bumper wheel
.	AS2106.02	Retaining screw
.	AS2106.03	Washer
.	AS2106.04	Lock nut
.	AS2107.01	Bumper wheel support
.	AS2107.02	Retaining screw
.	AS2107.03	Washer
.	AS2108.01	Carrying handle
.	AS2108.02	Washer
.	AS2108.03	Nuts
.	AS2109.00	Sanding drum exchange
.	AS2109.01	SANDING DRUM (REG 8in)
.	AS2109.02	SANDING DRUM SHAFT
.	AS2109.03	Woodruff key, drum
.	AS2109.04	Woodruff key, pulley
.	AS2109.05	Drum retaining nut
.	AS2109.06	Washer
.	AS2109.07	Drum pulley
.	AS2109.08	Retaining nut
.	AS2109.09	Washer
.	AS2110.01	Bearing flange, drum
.	AS2110.02	Mounting screws
.	AS2110.03	INNER BEARING COVER (REG.8)
.	AS2110.04	Mounting screws
.	AS2110.05	Roller bearing

.	AS2110.06	Locking ring
.	AS2110.07	Locking rings
.	AS2110.08	Drum bearing, drive side
.	AS2110.09	OUTER BEARING COVER
.	AS2110.10	Mounting screws
.	AS2111.01	TENSION ROLLER HOLDER
.	AS2111.02	Pressure spring
.	AS2111.03	Pressure piece
.	AS2111.04	Retaining screw
.	AS2111.05	Lock nut
.	AS2111.06	Tension lever
.	AS2111.07	Handle
.	AS2111.08	Mounting screw
.	AS2111.09	Lock nut
.	AS2111.10	Mounting bolt
.	AS2111.11	Retaining screw
.	AS2111.12	Washer
.	AS2111.13	Retaining screw
.	AS2111.14	Washer
.	AS2112.00	Tension roller complete
.	AS2112.01	TENSION ROLLER SHAFT
.	AS2112.02	Nut
.	AS2112.03	Washer
.	AS2112.04	External roller
.	AS2112.05	Ball bearings

.	AS2112.06	Retaining screw
.	AS2112.07	Inner roller
.	AS2112.08	Ball bearings
.	AS2112.09	Swivel bearing
.	AS2112.10	Packing ring
.	AS2112.11	Travel roller
.	AS2112.12	Locking rings
.	AS2112.13	Locking rings
.	AS2112.14	Locking rings
.	as2112.15	Washer
.	AS2112.16	Packing ring
.	AS2112.17	Locking ring
.	AS2112.18	Compensating washer
.	AS2112.19	Travel roller complete
.	AS2113.01	Fan flange
.	AS2113.02	Mounting screws
.	AS2113.03	Locking rings
.	AS2113.04	Fan shaft with pulley
.	AS2113.05	Bearing spacer
.	AS2113.06	Distance plate
.	AS2113.07	Ball bearings
.	AS2113.08	FAN
.	AS2113.09	Washer
.	AS2113.10	Retaining nut
.	AS2114.01	Steering head

.	AS2114.02	DUST PIPE
.	AS2115.01	Cable arm
.	AS2115.02	Cable arm bracket
.	AS2115.03	Mounting screws
.	AS2115.04	Locking screw
.	AS2115.05	Pressure spring
.	AS2116.01	Right handgrip with plate
.	AS2116.02	Control Rod
.	AS2116.03	Spacer for screw
.	AS2116.04	Retaining screw
.	AS2116.05	Washer
.	AS2116.06	Locking screw
.	AS2116.07	Locking washer
.	AS2116.08	Washer
.	AS2116.09	Left handgrip
.	AS2116.10	Coverplate
.	AS2116.11	Retaining screws
.	AS2116.12	Height regulating lever
.	AS2116.13	Plastic grip
.	AS2116.14	Grip
.	AS2116.15	Grip
.	AS2117.00	Castor wheel complete
.	AS2117.01	Castor wheel fork
.	AS2117.02	Locking rings
.	AS2117.03	Inner ball bearing

.	AS2117.04	Outer ball bearing
.	AS2117.05	Castoring shaft
.	AS2117.06	Locking ring
.	AS2117.07	Lock nut
.	AS2117.08	Washer
.	AS2118.01	Retaining screws
.	AS2118.02	Spring tooth lock washer
.	AS2119.01	Castor wheel axle
.	AS2119.02	Castor wheel felloe
.	AS2119.03	Ball bearings
.	AS2119.04	Tire
.	AS2119.05	Locking ring
.	AS2119.06	Felloe Cover
.	AS2119.07	Retainiing screws
.	AS2120.01	AXEL
.	AS2120.02	Locking rings
.	AS2121.01	RUNNING WHEEL BRACKET
.	AS2121.02	STAR KNOB/COMPLETE
.	AS2121.03	LOCK NUT
.	AS2121.04	Connection screw
.	AS2121.05	SPACER
.	AS2121.06	Clam
.	AS2121.07	Cam Adjustment screws
.	AS2122.01	Wheel axle screw (short)
.	AS2122.02	Distance washers

.	AS2122.03	Wheel axle screw (long)
.	AS2122.04	Spring tooth lock washer
.	AS2122.05	Lock nut
.	AS2123.01	Spacers, running wheel axle
.	AS2123.02	Running wheel felloes
.	AS2123.03	Ball bearings
.	AS2123.05	Locking rings
.	AS2123.06	Felloe covers
.	AS2123.07	Retaining screws
.	AS2124.01	Locking screws
.	AS2124.02	Nuts
.	AS2124.03	Kurled nut
.	AS2125.01	BELT GUARD (REG 8")
.	AS2125.02	Axle
.	AS2126.00	110 Volt Motor
.	AS2126.01	12 GAUGE CORD PER FT. (1.5 HP)
.	AS2126.02	Bag
.	AS2126.03	3L260 FAN BELT(MOTOR)OLD GREEN
.	AS2126.04	3L350 DRIVE BELT FOR 1.5HP MTR
.	AS2126.05	Pulley on Motor
.	AS2126.06	ON/OFF BREAKER SWITCH 1.5
.	AS2126.08	TOOL KIT REG. 8
.	AS2126.09	FRONT MOTOR BRACKET (OLD)
.	AS2126.10	Rear motor bracket
.	AS2126.11	1.5HP RUNNING CAPACITORS

.

AS2126.12

1.5HP STARTING CAPACITORS